

Key-Safe Operation



1. Pull down the protective cover. (Not shown on the picture.)
2. Make sure that the 'Open Handle' is in the Open position - the word 'Open' is the right way up.
3. Slide the 'Clear Switch' down.
4. Input the code using the buttons. **Make sure that each button is fully depressed.** You should hear/feel a slight click.
5. If you make a mistake, slide the 'Clear Switch' down and start again.
6. Turn the Open handle clockwise 180° so that the word 'Open' is upside-down. Towards the end of the turn, the front should hinge down.
7. Remove the keys
8. Close the safe and lock it by turning the Open handle anti-clockwise 180° back.

Do not rotate the Open handle whilst the safe is open, except to close it.

Problems

Open handle rotates but the safe won't open:
Restart from step 2

The safe won't close:
This means that the Open handle has been moved whilst the safe is open.
Go through steps 2 to 7